

6940 State Rd.-C  
Philadelphia, PA 19135  
Tel: (215) 824-4100  
Fax: (215) 824-1371  
Website: [www.rmcmmedical.com](http://www.rmcmmedical.com)  
Email: [rmcmmed@verizon.net](mailto:rmcmmed@verizon.net)



Emergency Response Equipment  
Decontamination Equipment  
EMS Equipment & Supplies  
Training Videos & Training Seminars

## **RMC MEDICAL**

### **HAZMAT DECON SHOWER** **HDS-6012** **INSTRUCTION SHEET**

**Read all instructions completely before assembling.**

**For ease, portability and storage, the shower is broken down into 12 parts, all color coded.**

**RED.....Base and lower supports**  
**YELLOW....Upper supports**  
**BLUE.....Top half vertical supports**  
**GREEN.....Center horizontal supports**  
**ORANGE....Center overhead shower sections**

**Color bands appear on all sections. Match red to red, yellow to yellow, blue to blue, green to green and orange to orange.**

#### **ASSEMBLY**

- 1) Assemble shower in 2 sections (upper and lower). Fig. 1**
- 2) Connect all red to red, green to green (lower section).**
- 3) As an option, attach standard garden hose to on/off valve assembly and fill lower section of shower with water. This will assure stability before attaching upper section.**
- 4) Connect all blue to blue and orange to orange (upper section).**
- 5) Connect all yellow to yellow (upper section to lower section).**
- 6) Make sure that horizontal side bar (green) is perpendicular to horizontal ground bar (red). This assembly configuration gives the shower greater stability.**